

COBRA

Items Supplied >

- 2 - Floorboard Assemblies with Mounts
- 2 - M8 x 40mm Hex Bolts
- 4 - Flat Washers
- 2 - M8 Nylock Nuts

Application(s) >

Suzuki Boulevard C90 05-09

Instruction Manual >

06-3840/06-4840

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove your original passenger foot pegs from their mounts.
2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied M8 bolts, washers and nylock nuts.
3. Check to make sure that the bolts are tight prior to riding the motorcycle.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.