

# COBRA

## Items Supplied >

- 1 – Left Floorboard
- 1 – Right Floorboard

## Application >

HONDA SABRE 00-07

## Instruction Manual >

06-1635/06-4135

1. Remove the brake light switch and right stock foot peg mount making note of where the brake spring tensioner is positioned on the brake pedal.
2. Install the right front floorboard, positioning the spring tensioner loop in the top rear hole on the mounting bracket. Secure mount using your stock hardware. Re-install the brake light switch and adjust as necessary.
3. Remove your left stock foot peg mount.
4. Install the left front floorboard using your stock hardware.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

***Anything's Possible.***