

# COBRA

## Items Supplied >

- 1 - Left Floor Board Assembly
- 1 - Right Floor Board Assembly
- 1 - 8mm Acorn Nut

## Application(s) >

HONDA VTX1800C 02-UP  
HONDA VTX1800F 05-UP

## Instruction Manual >

06-1650/06-4150

Page 1 of 2

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

### Left Side

1. Unplug the horn wires.
2. Unbolt the left side foot peg bracket assembly and save the hardware, the stock bolts will be used to install your new Cobra floorboards.
3. Remove horn and the shift lever from the stock mount and install onto the new Cobra mount the same way they were on the stock mounts. Install the 8mm acorn nut on the exposed threads from the shift lever bolt.
4. Bolt the Cobra floorboards to the motorcycle using the stock bolts and torque to factory specifications.

**Note:** Make sure shift lever operates properly and that there is adequate clearance.

### Right Side

1. Remove chrome cover from the top of the rear brake master cylinder by removing the two nuts on top.
2. Remove brake lever return spring and the stop light switch spring.
3. Remove rubber plug from the center of the brake lever pivot bolt then remove the bolt.
4. Remove the two bolts that hold the master cylinder and brake light switch/chrome cover mount.
5. Unbolt the right side foot peg bracket by removing the two stock 10mm bolts and save the hardware, the stock bolts will be used to install your new Cobra floorboards. **Note:** look at the placement of the large spacers behind the foot peg bracket they will need to be re-installed in the same position. Also note the nut on the inside of frame rail for lower bolt.
6. Install the Cobra floorboard using the stock bolts and spacers removed in previous step.
7. Remount the master cylinder and brake light switch/chrome cover mount removed in step 4 the same way it was on the stock mount bracket, reuse stock hardware.
8. Install the brake lever using the stock pivot bolt & rubber plug that was removed in step 3.

\* *Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

**Anything's Possible.**

9. Install the brake lever return spring and the stop light switch spring the same way they were installed on the stock foot peg bracket
10. Install the stock chrome cover and guard using the stock nuts removed in step 1.
11. Tighten all hardware to factory torque specifications.
12. Test brake lever to make sure it is operating properly and that the brake light switch is properly adjusted.