

COBRA

Items Supplied >

1 - Set Of Plated Floorboards

Application(s) >

HONDA VTX1800 RETRO
HONDA VTX1300 RETRO
HONDA VTX1800N

Instruction Manual >

06-1660/06-4160

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

1. Remove your stock floorboard by removing the e-clip and the pin from the stock front floorboard and disconnecting the spring from the board.
2. Install Cobra floorboard the same way stock one was installed reusing the pin, e-clip and attaching spring to the hole in the support block in the middle of the Cobra floorboard.
3. Repeat steps for other side.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.