

COBRA

Items Supplied >

2 - Floorboard Assemblies with Mounts
2 - 5/64 x 1/2" Cotter Pins

Application(s) >

YAMAHA RAIDER

2008-2014

Instruction Manual >

06-4265

Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove cotter pin from retaining pin on front foot peg
2. Remove foot peg retaining pin, spring and foot peg from pivot.
3. Replace foot peg with new Cobra Floorboard and reinstall retaining pin and spring.
4. Install new supplied cotter pin thru Floorboard retaining pin and bend accordingly.
5. Repeat on opposite side.

**Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.®