

COBRA

Items Supplied >

2 - Floorboard Assemblies with Mounts
2 - 5/64 x 1/2" Cotter Pins

Application(s) >

YAMAHA STRYKER

2011-2014

Instruction Manual >

06-4270

Read all instructions carefully and completely before installing your new Cobra® floorboards.

1. Remove cotter pin from clevis pin on front footpeg
2. Remove the clevis pin, spring, spacer and footpeg from pivot.
3. Install new Cobra® Floorboard using stock clevis pin, spring and spacer in the same manner as stock.
4. Install new supplied cotter pin through clevis pin and bend accordingly.
5. Repeat on opposite side.

**Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.®