

COBRA

Items Supplied >

- 1 – Front Exhaust
- 1 – Rear Exhaust
- 1 – Front Heat Shield w/clamps
- 1 – Rear Heat Shield w/clamps

Application >

KAWASAKI VULCAN 800 95-UP

Instruction Manual >

4164SC/4264

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

NOTE: If you have Cobra front floorboards #06-1920, do step #6 first.

1. Remove stock exhaust system.
2. Install stock exhaust gaskets onto exhaust head pipes.
3. Install exhaust using all stock hardware.
4. Finger tighten all bolts and check clearance on exhaust.
5. Tighten all bolts.
6. Install the front and rear full-length heat shields using the supplied hose clamps

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-4164.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

Anything's Possible.