

Items Supplied >

- 1 - LEFT DETACHABLE MTG BRACKET
- 1 - RIGHT DETACHABLE MTG BRACKET
- 6 - 5/16 BUTTONHEAD BOLTS
- 6 - 5/16 FLAT WASHERS

Application(s) >

HARLEY:
DRESSER

09-13

Instruction Manual >

602-2100

Page 1 of 1

Read all instructions carefully and completely before installing your new Detachable Mounting Kit!

NOTE: This kit will allow you to install Cobra detachable accessories and Harley detachable accessories. Please see the catalog for more details.

1. Remove the saddle bags carefully.
2. If this mounting kit is being installed on a CVO Streetglide or CVO Roadglide, remove the stock 2-point docking brackets.
3. Starting on the right side, remove the screw holding the frame cover in place. See **FIGURE 1**.
4. Attach the right side bracket to the outside of the rear frame section using the supplied 5/16" flat washers and buttonhead screws. **DO NOT TIGHTEN** bolts at this time. See **FIGURE 2**.
5. Do the same for the left side. **DO NOT TIGHTEN** bolts at this time. **NOTE:** If this mounting kit is being installed on a CVO Streetglide or CVO Roadglide, you may need to install the antennae mounting bracket to the outside of the left mounting bracket.
6. Before fully tightening the screws, ensure the detachable backrest and luggage rack attach properly. Refer to the instructions that came with each accessory before installing.
7. When all accessories fit well then tighten the screws on each bracket. Be sure to recheck the tightness after the first ride and after the first 500 miles. See **FIGURE 2**.
8. Re-install the saddle bags.



REMOVE
SCREW

FIGURE 1



RIGHT SIDE
MOUNTING
BRACKET

FIGURE 2

SUPPLIED
SCREWS AND
WASHERS

*** Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**