



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

Triumph
ROCKET 3

REMOVAL:

- 1) Remove right heel guard (2-bolts).
- 2) Remove muffler heat shield (1- bolt, slide forward).
- 3) Remove stock exhaust muffler assembly (1- clamp, 3- bolts, carefully pull away and unscrew O2 sensor).
- 4) Remove bushing from center exhaust bolt location and store with your stock exhaust

INSTALLATION:

- 1) Carefully transfer stock exhaust flange gasket to the WerkesUSA exhaust.
- 2) Install O2 sensor to back of y-pipe portion of the upper WerkesUSA canister.
- 3) Clamp upper WerkesUSA canister onto stock headpipe (leave slightly loose until after next step).
- 4) Install lower WerkesUSA canister (use stock bolt/nut, and supplied clamp) Adjust/align exhaust canisters as desired before tightening clamps and hardware securely.
NOTE The clamps and mounting hardware/bracket all work together to support your WerkesUSA exhaust system. Tighten them securely. Check periodically (we recommend every 1000 miles).
- 5) Transfer u-nut from stock heatshield mount to the WerkesUSA exhaust.
- 6) Install stock heat shield using stock hardware.
- 7) Install heel guard.
- 8) Clean exhaust of fingerprints and grime using WD-40 (or similar) before starting.

PARTS LIST:

1- Upper Exhaust Canister 1- Lower Exhaust Canister 1- 2" Clamp

****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****



Learn more about motorcycle exhaust on our website.

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WT2500