

## Water Supply Hose

Made in the U.S.A

Congratulations on your purchase of the world's finest [cooling system](#)

### Included with your system:

<u>Quantity</u>	<u>Description</u>
_____ 1	12 foot hose
_____ 2	Male connector
_____ 2	Female Connector
_____ 4	Connector Clip Rings

### Instructions For Use:

- 1) Cut Water Supply Hose to your desired length, preferably with scissors.
- 2) First, slide one connector clip ring over rubber interline tubing as far back as possible prior to inserting connectors. Next, gently stretch the interline tubing open with a pair of needle nose pliers.
- 3) For best results, barbed end of connectors may be lubricated with water before being inserted into rubber tubing. Insert the barbed ends of male and female PRC-2 connectors into the rubber interline tubing until tube is fully seated against the connector. With all four connectors inserted in tubing, slide connector clip rings towards fitting base, so all fittings are secured.

**Your end result should look like the pictures below**

