

## **Installation Instructions**

### **CE-208**

**The CE-208 will fit 1994 to 2005 all Sportster models.**

Regulator-Remove Old Regulator

- 1) Starting from the regulator, follow the wires to the plugs. Disconnect both plugs.
- 2) Unbolt the regulator and remove it.

### **Install New Regulator**

- 1) Mount new regulator. Use the stock mounting bolts with the star washers supplied. Insert star washers between the bolt head and the regulator. This will insure the regulator has a good ground connection.
- 2) Connect stator and battery plugs.
- 3) Start motor and Test battery voltage. Voltage at the battery should run between 14.2 and 14.6.