

**FOR OFF ROAD/RACE USE ONLY!**



## ***Driven Rear Axle Block Sliders***

***Part#: DRAX-XX***

### ***INSTALLATION INSTRUCTIONS***

#### **Removal**

1. Position bike in an upright position (preferably on a motorcycle work bench with a front wheel chock and rear stand)
2. Loosen up the rear wheel axle nut.
3. Lift the rear of the bike off the ground.
4. Remove rear axle.
5. Remove OEM axle block.

#### **Installation**

##### **Sprocket Side:**

1. Locate left side part.
2. Install Driven Axle Block with the bolt hole facing down, install slider.

##### **Brake Side:**

1. Locate right side part.
2. Install Driven Axle Block with the bolt hole facing down, install slider.
3. Install axle nut washer.
4. Adjust chain tension and torque axle nut following your owner's manual.
5. Torque slide to 45 ft/lbs using blue Loctite.

***THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN\****