

**FOR OFF ROAD/RACE USE ONLY!**



**Driven Universal Toe Guard**

**Part#: DUTG-XX**

**INSTALLATION INSTRUCTIONS**

**Note: Will only work on a Straight Square swing arm**

**This product must be installed by a qualified mechanic.**

### **Installation**

1. Choose the area you want to mount the toe guard.
2. Use the supplied sticker and stick it at the mounting location you choose.
3. Using a punch, center punch the 2 + symbols on the sticker to make sure the drill won't "walk".
4. Using a W size drill, drill the 2 holes (make sure you drill straight).
5. Push the 2 included rivnuts into the hole.
6. Use the tool supplied to expand the rivnut inside the swing arm hole you drilled. (See Fig 1)
7. Install the shark guard using the 2 M6 screws supplied please use Loctite.

**Warning: measure everything twice and make sure you do it right. Driven performance products is not responsible for any and all damages that will accrue during improper installation.**

**THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!**

### **TOOLS REQUIRED**

- Center punch
- Drill
- Size W drill bit
- Rivnut installation tool (included)
- 10 mm open end wrench
- 5mm Allen key
- 4mm Allen key
- Loctite



Fig 1

**THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN\***

Find out more about custom accessories & trim we have.