



PART#: DXM (DRIVEN BAR END MIRROR)



(optional bar end adapter, part# DMR-2)

1. Remove mirror from tin box.
2. Take mirror bracket and loosen 5 mm bolts. Install in desired position onto 7/8 bar or optional bar end adapter and tighten snugly.
3. Install flat ball into mirror body with supplied 5 mm bolt and tighten to 5 ft/lbs of torque use blue or red loctite (red will make it hard to remove).
4. Slide both mirror ball and bar clamp ball into mirror bracket and tighten both 5mm bolts on bracket face until they are snug.
5. Adjust the mirror to desired position turn both 5mm screws on bracket face one more ¼ turn.
6. Ride for 5-10 miles and tighten or adjust as necessary. DO NOT OVER TIGHTEN!

Discover other frame & body on our website.