EE Right Fork Leg Guard Installation Instructions









- 1 Using a 10mm t-handle or socket remove both of the right side axle pinch bolts. (Fig 1)
- 2 Place the provided spacers on the 8 x 35mm Hex head bolts as shown. (Fig 2)
- Place the 8 x 35mm Hex head bolts with the spacers in place of the original pinch bolts to install the fork guard as shown. (Fig 3)
- Using a torque wrench with a 10mm socket, torque the pinch bolts to the manufacturer's torque specifications. (Fig 4)



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Right Fork Leg Guard

Part# 32-246