

EE Fork Guard Installation Instructions



**Enduro
Engineering**

QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

EE Fork Guard

Part# 32-254

- 1 Using a 10mm t-handle or socket remove both of the right side axle pinch bolts. (Fig 1)
- 2 Use the provided longer 8 x 40mm Hex head bolts in place of the original pinch bolts to install the fork guard as shown. (Fig 2)
- 3 Using a torque wrench with a 10mm socket, torque the pinch bolts to the manufacturer's torque specifications. (Fig 3)