

Instructions: Over Bar Stabilizer Mount

Thank you for purchasing the Fastway Over Bar Stabilizer Mount. We have designed this system to be as easy to install as possible and accommodate a large range of applications.

1. Mount Top Bar Clamp



- a. Remove the 4 bolts that hold the top bar clamps in place and remove the clamps.

Note: There is no need to remove the handle bars.

- b. Install two flat head bolts in the stabilizer mounting plate to the Fastway top clamp. A tight fit is normal.
- c. Install the Fastway top bar clamp using the four M8 bolts supplied. It is critical to use the supplied bolts to ensure proper fit and clearance. Evenly tighten the bolts to ensure that the top clamp is an even and parallel distance from the bottom handlebar risers.

2. Stabilizer Mount Plate



- a. Install the stabilizer mount plate on the top clamp tight enough so it will stay in place but loose enough so it can be moved.
- b. Mount the Fastway Steering Stabilizer to the stabilizer plate and center the adjustment knobs over the steering axis. It may be necessary to adjust the height of the tower pin, see frame clamp instructions.
- c. Turn the handle bar in both directions and verify that the bar turns to the steering stops, if not move the stabilizer plate forward about 1/8" and re-check the steering movement. Make sure there is no interference with any portion of the stabilizer system.
- d. Remove the stabilizer and tighten the stabilizer plate mounting bolts.
- e. Once the stabilizer plate has been properly tightened, reinstall the steering stabilizer.