

Instructions – PMB-01-2009

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

1-10x30 Modified Socket-head Bolt

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the left footpeg and bracket.
2. Install the kickstand under the left footpeg bracket using the stock bolt on the bottom and the new supplied bolt on the top.
3. Make sure that you tighten the footpeg bracket bolts to the correct torque as specified in your owner's manual.
4. Once the kickstand has been installed, slowly move the kickstand through its motion to ensure it doesn't catch on anything. If the left rear side panel has been bent in the plastic may need to be heated with a heat gun and bent or pulled out to avoid interfering with the kickstand.
5. Re-install the footpeg.
6. Periodically check the footpeg mounting bolts, and kickstand pivot bolt for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.