



## **Instructions: PMB-01-3210**

We recommend using a removable thread-locking agent on all bolts.

1. Remove the stock cargo rack and grab handles.
2. Place the rack on the bike with the tapered spacers between the rack and the rear fender, with the shorter spacers at the rear mounting holes.
3. Loosely install the rack using the two 8x45mm flat head bolts in the rear mounting holes, with the shorter spacers between the rack and the grab handle mounting holes.
4. Install the 8x60 flat head bolts into the front mounting holes, with the two larger spacers between the rack and the grab handle mounting holes.
5. Tighten the rack top.
6. Make sure that all bolts are tight and enjoy. Periodically check the mounting bolts to make sure they are tight.

**CAUTION:** As with all racks on motorcycles they should not have excess amounts of weight put on them. Excess weight can damage the rear sub-frame of the motorcycle.

### **Parts List:**

1-Top  
2-8 X 18.5 X 39 Tapered Spacer  
2-8 X 18.5 X 24.5 Tapered Spacer  
2-8x45 FH  
2-8x60 FH  
1-Loctite Packet

