

## Instructions – PMB-01-4005

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

### **Parts List:**

1-Kickstand

1-8x35 FH

1-8x80 FH

**NOTE:** We recommend using a thread-locking agent on all bolt threads.

### **To install your new kickstand:**

1. Remove the lower chain roller and bolt; make sure you keep track of the order of the small parts for re-assembly. The stock nut and washers will be reused but the stock bolt will not. Remove the sub-frame to main-frame bolt.
2. Insert the 8x80mm flat head bolt into the lower hole on the kickstand mounting bracket and the chain roller bracket on the frame.
  - a. Install one stock 8mm washer on the bolt on the back side of the chain roller bracket.
  - b. Install the chain roller onto the bolt.
  - c. Install one stock 8mm washer and stock nut on the bolt. Do not tighten yet.
3. Install the 8x35mm flat head bolt at the sub-frame.
4. Tighten both bolts to the correct torque.
5. Periodically check the kickstand leg pivot bolt and all mounting bolts for tightness.

### **To prevent damage:**

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.