



**AB016**

**BMW Smog Block-Off Plates**  
**BMW S1000RR 2010-2014**

**PARTS LIST**

- Smog Block Off Plates 2
- Airbox Cap 1



**<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>**

- 1) Make sure the bike is off and has had time for the motor and components to completely cool off.
- 2) Carefully remove the fairings, fuel tank and air box.
- 3) Use a short 5mm Allen wrench to remove the bolts from the smog port covers. The bolts have loctite and will be very tight.
- 4) Apply blue loctite to the stock bolts and install the smog block off plates.
- 5) Remove the air hose leading from the airbox to the smog port and cover the outlet with the included cap. Be sure to secure the cap with a zip tie or safety wire.
- 6) Reinstall the airbox, fuel tank, and fairings.



**More Graves Parts for your BMW**



**FEB-10S1RR-K**  
**BMW Fender Eliminator Kit**



**EXB-14S1RR-SOT**  
**BMW Slip-On**

The purchaser releases Graves Motorsports, Inc from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident. **This product is intended for Closed Course Competition Use Only** and may render the vehicle illegal for use on public roads.