



# FSK-20ZH2-K

## Parts List:

**Spacer (Right + Left) – 2**

**Frame Slider Left – 1**

**Pressed Spacer (Right + Left) – 2**

**Frame Slider Right – 1**

**M10 x 70MM x 1.25 Hex Head Bolts - 2**

1. Remove the left front engine bolt. Note: Check to see if the engine mount hole lines up with hole in the frame after removing the engine bolt. If not place a small scissor jack under the motor and using a small block of wood to protect the engine from damage slowly jack up the motor until it lines up before installing the Graves frame slider kit.
2. Torque the frame slider bolt to 40nm 33ft-lbs
3. Remove the Right front engine bolt. Note: Check to see if the engine mount hole lines up with hole in the frame after removing the engine bolt. If not place a small scissor jack under the motor and using a small block of wood to protect the engine from damage slowly jack up the motor until it lines up before installing the Graves frame slider kit.
4. Torque the frame slider bolt to 40nm 33ft-lbs