



HB002

PARTS LIST

- Brake Lever Guard 1
- Mounting Nut 1
- Bolt 1
- Expansion Collet 1

ALUMINUM BRAKE LEVER GUARD INTENDED FOR USE WITH GRAVES CLIP-ON HANDLEBARS (HB050)

<<<<INSTALLATION OF THIS PRODUCT SHOULD BE PERFORMED BY A **QUALIFIED TECHNICIAN** >>>>
<<<<<<PLEASE READ INSTRUCTIONS CAREFULLY BEFORE BEGINNING INSTALLATION >>>>>>

This product is intended for use with the Graves Clip-On Handlebars or Handle Bar Tubes ONLY

DO NOT: Lube any parts before installation. Anti-seize compound has been applied to the threads of the mounting nut for your convenience.

NOTE: Be sure the end of the handlebar tube is clean and clear of any grease, oil or debris or the lever guard will not tighten properly.

- 1) Insert the brake lever guard assembly all the way into the handlebar tube until it stops.
- 2) Tighten the bolt enough to keep the lever guard on the handlebar and rotate up and down until the lever guard is positioned in the optimal location to protect the rider's hand and the brake lever.
- 3) Once the lever guard is in the desired position make sure the face of the lever guard is in complete contact with the bar end. Make sure there is 2mm of clearance from the grip and throttle tube then tighten the bolt to 25.8 ft.-lbs. / 35Nm. **(PHOTO 1)**



PHOTO 1

- 4) Check that there is at least 10mm of clearance from the tip of the brake lever to the brake lever guard throughout the entire lever stroke. **(PHOTO 2)**



PHOTO 2

This Kit works best when paired with:



Graves Clip-On Handlebars - HB050

The purchaser releases Graves Motorsports, Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident. **This product is intended for Closed Course Competition Use Only** and may render the vehicle illegal for use on public roads.