



+0mm
(stock OEM)

+10mm

+20mm

RECOMMENDED SHIFT TIP SIZING:

For Boot Size	7	8	9	10	11	12	13	14
Use Tip Offset	0	0	0	+10	+10	+10	+20	+20

US Patent #: 7,278,336



On our website you can discover more about motorcycle foot controls & pegs.