

# DK470 DIN RADIO INSTALL KIT

## KIT CONTENTS



- 1 - DB235 DIN BEZEL (C)
- 1 - DC235 DIN CRADLE (D)
- 1 - INSTALLATION HARDWARE KIT
  - 1 - M4X8 BOLT AND LOCK WASHER FOR DIN CRADLE (F)
  - 2 - RUBBER BUMPER PADS FOR DIN CRADLE (E)
  - 1 - RUBBER O-RING FOR DIN BEZEL

## INSTALLATION INSTRUCTIONS

1. REMOVE THE OUTER SLEEVE (B) FROM THE SOURCE UNIT (A).
2. SLIDE THE BEZEL (C) OVER THE SLEEVE FROM THE BACK WITH THE RECESS IN THE BEZEL FACING TOWARD THE SOURCE UNIT FACEPLATE.
3. INSERT THE SLEEVE AND BEZEL INTO THE CRADLE (D) FROM THE FRONT.
4. WITH THE SLEEVE AND BEZEL AS FAR BACK IN THE CRADLE AS POSSIBLE, FOLD OUT THE TABS ON ALL SIDES OF THE SLEEVE TO HOLD THE THREE PARTS TOGETHER.
 

**NOTE:** MAKE SURE THE BENDING TABS ARE NOT PROTRUDING OUTSIDE OF THE BEZEL.
5. INSTALL RUBBER BUMPER PADS (E) INTO THE 2 HOLES ON THE BOTTOM OF THE CRADLE.
6. SLIDE THE SOURCE UNIT (A) INTO THE SLEEVE ASSEMBLY FROM THE FRONT UNTIL IT LOCKS OR SNAPS INTO PLACE.

