



BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

PART NO. 41-156

3PC LID NET SET-TRUNK
AND SADDLEBAG
CAN-AM SPYDER RT

TOOLS NEEDED: TORX T20 DRIVER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

SECTION ONE – INSTALLING TRUNK LID NET

1. USING THE T20 TORX DRIVER REMOVE THE 4 SCREWS AS SHOWN IN FIG. 1
2. REINSTALL THE TORX SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF IT WERE A WASHER, LEAVING THE “S” HOOK HOLE POINTING IN TOWARD THE CENTER OF THE TRUNK LID. SEE FIG. 1
3. ATTACH ONE OF THE NETS FROM THE KIT TO THE MOUNTING CLIPS AS SHOWN IN FIG. 1

SECTION TWO-INSTALLING SADDLEBAG LID NETS

1. USING THE T20 TORX DRIVER REMOVE THE 4 SCREWS AS SHOWN IN FIG. 2
2. REINSTALL THE TORX SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF IT WERE A WASHER, LEAVING THE “S” HOOK HOLE POINTING IN TOWARD THE CENTER OF THE SADDLEBAG LID. SEE FIG. 2
3. ATTACH ONE OF THE NETS FROM THE KIT TO THE MOUNTING CLIPS AS SHOWN IN FIG. 2
4. REPEAT ON OTHER SADDLEBAG.



FIG. 1



FIG. 2