

# INSTALLATION INSTRUCTIONS

PART NO. H40-403BK

COVER FOR MAX MOUNT

FITMENT: CAN-AM RYKER 2019-NEWER

TOOLS NEEDED: N/A

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.  
ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

## INSTALLATION:

1. REMOVE THE MAX MOUNT COVER FROM THE PACKAGE.
2. FROM THE REAR OF THE RYKER, CAREFULLY SLIDE THE MAX MOUNT COVER ONTO THE MAX MOUNT (FIG. 1). COVER WILL FIT TIGHT ON FIRST INSTALL. BE SURE MAX MOUNT COVER IS SLID ALL THE WAY ON BEFORE MOVING TO STEP 3.
3. GO TO THE LEFT SIDE OF THE RYKER AND PULL THE LEFT FRONT OF THE COVER DOWN AND UNDER THE MAX MOUNT AND SECURE WITH A THUMBSCREW AS SHOWN IN FIG. 2. NOTE: COVER WILL BE TIGHT THE FIRST TIME IT'S INSTALLED. USE CAUTION WHEN INSTALLING TO NOT RIP OR DAMAGE.
4. REPEAT STEP 3 ON THE RIGHT SIDE.

FIG. 1



FIG. 2



## NOTICE

IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.