

TOOLS NEEDED:	5/32" ALLEN WRENCH	RUBBING ALCOHOL	LINT FREE TOWEL	THREAD LOCK COMPOUND	3/8" WRENCH
	PHILLIPS SCREWDRIVER				

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 15 TO 30 MIN.

USE A REMOVABLE THREAD LOCK ON ALL FASTENERS.

INSTALLATION:



1. USING A PHILLIPS SCREWDRIVER REMOVE THE SCREW AT THE BACK OF THE SEAT. SEE FIG. 1.
2. REMOVE THE SEAT. SET ASIDE.
3. USING A 3/8" WRENCH REMOVE THE BOLT HOLDING THE BACK OF THE CONSOLE TO THE BIKE. SEE FIG. 2.
4. ON THE FRONT OF THE CONSOLE USING A 5/32" ALLEN WRENCH REMOVE THE SCREW SHOWN IN FIG. 3.
5. OPEN THE FUEL DOOR AND REMOVE THE GAS CAP.
6. LIFT THE CONSOLE UP AND USING A LINT FREE TOWEL AND RUBBING ALCOHOL CLEAN THE BACK OF THE TANK AND UNDER EACH SIDE OF THE TANK.
7. LAY THE MINI BRA INTO PLACE ON THE GAS TANK AND USING THE SEAM ON THE BACK EDGE CENTER THE MINI BRA ON THE TANK.
8. REMOVE THE FILM FROM THE TWO 3" LONG PIECES OF HOOK ATTACHED TO THE BACK OF THE BRA AND ATTACH THEM AS SHOWN IN FIG. 4.
9. WITH THE BRA ATTACHED IN THE BACK PULL EACH SIDE TIGHT AND PLACE EACH PIECE OF HOOK UNDER THE SIDE OF THE TANK. SEE FIG. 5.
10. REINSTALL SEAT. ONCE THE SEAT IS ON READJUST THE BRA SO THAT IT IS TIGHT.
11. LET TAPE CURE FOR 24 HOURS AND THEN ADJUST TENSION OF MINI BRA TO TAKE OUT ANY LOOSE AREAS.

