



WARNING!

Before Installation Clean IMS Tank Interior Thoroughly. Install This Fuel Tank ONLY In a Well Ventilated Area, As Gasoline Fumes Are EXTREMELY Dangerous. DO NOT START OR OPERATE THE VEHICLE IF THERE ARE ANY FUEL LEAKS!

IMS Recommends Installation Be Performed By a Licensed Mechanic. Improper installation may result in Severe Injury or Death. Read All Instructions Prior to Installation.

KAWASAKI:

Fits 1991-13, KX 80/85/100

FUEL TANK:

2.4 GALLON

IMS TANK ID: KX-26

IMS Part #:

113134 / 213134

PARTS LIST

- (1) Fuel Tank
- (1) Gas Cap & Seal
- (1) Petcock Gasket
- (1) "CR-2000" Front Mount Bracket
- (1) 6mm x 25mm 10 Hex, 13 Flange Screw
- (1) 6mm x 40mm Hex Screw
- (1) 6 mm x 25mm Flat Washer
- (2) L-Brackets "3133-L"
- (1) S-Bracket "IMS-3133-S"
- (4) 6mm x 12mm 8mm Hex, 10mm Flange Screw

Instruction for 1991-2000

- (2) Back shroud "L" brackets (98-00 uses only one bracket for left shroud)
- (4) 6 x 12mm Bolt With 8mm Head
- (1) S-Bracket For Left Side Shroud
- (2) Large O.D. Flat Washers 6mm
- (1) 6 x 40mm Bolt (for Front Shroud Bracket To Frame)

Instructions for 2001-2009

- (2) 6 x 12mm Bolts With 8mm Head
- (1) 6 x 25mm Flat Washer
- (1) CR Front Bracket (With Rubber Grommet & Short Sleeve)
- (1) 6 x 25mm Flange With 10mm Head

STOCK ITEMS TO USE

- Petcock, Seat Hook, Mounting Bracket & Bolts.

TANK REMOVAL

Drain fuel from OEM tank into government approved fuel container with a greater capacity than OEM tank on vehicle. Disconnect fuel line from carburetor. Take off seat, shrouds and OEM fuel tank. Remove mounting bracket from your OEM tank (1991-2000 only), seat hook and the petcock.

MODEL NOTES

1991-1997 models require a pair of 2001 or later KX 85/100 shrouds.

1998-2000 models require one left side 2001 or later KX 85/100 shroud.

2000 and earlier models – Unbolt ignition coil and flip it over. Reattach with spark plug lead next to outside frame rail.

1991-2009 reroute all electrical cables to the outside of the frame to make way for the new tank.

TANK INSTALLATION

Transfer Seat Hook and Petcock to IMS Tank

Petcock installation - Place supplied gasket between tank and petcock flange

FOR THE 2001-2009 MODELS

Attach the CR front bracket to the frame using the 6x25 flange head bolt and the 6x25 flat washers. Place IMS tank into the frame. Bolt the tank to the CR bracket using the (2) 6 x 12 bolts with 8mm head. Remount shrouds and seat. Attach the fuel line, fill up the fuel tank check for leaks and enjoy the ride!

FOR THE 1991-2000 MODELS

For 1991-1997: attach the (2) L-brackets to the rear of the IMS tank using (2) 6 x 12mm bolts with 8mm heads. These are mounting points for the new shrouds.

For 1998-2000: Requires only (1) L-bracket on the left side of the IMS tank using (1) 6 x 12mm bolt with 8mm head.

For 1991-2000: Attach the OEM bracket to the bottom of the IMS tank using the OEM bolts. Set the IMS fuel tank into the frame. Push the 6 x 40mm bolt & large O.D. washer through IMS S-bracket then the OEM tank bracket and bolt to the frame. This is the lower mounting point for the left shroud.

Attach the left side shroud using (1) 6 x 12mm bolt with 8mm head into the s bracket. Attach the right shroud, seat, and fuel lines.

Fill up the fuel tank check for leaks and enjoy the ride!

"FOR COMPETITION USE ONLY"

"Legal in California ONLY for racing vehicles which may never be used upon a highway."

DISCLAIMER:

Due to uncontrolled variables in the manufacturing process of rotationally molded fuel tanks, the fuel tank may vary in size and shape by up to 7% of the manufacturer's original listed capacity