



**Saddlebag-Lid Kit
w/ROKKER® XXR 5X7”
Speakers & Plug-n-play Wiring
Harness Included for
2014-2019 Harley® Baggers**

#HSBL-145X7-XXR

**Installation
Instructions**

Product Overview



This complete custom saddlebag-lid kit with ROKKER XXR 5X7" speakers, custom grills & Harley spec plug-n-play wiring harnesses included, has been designed for the 2014-2019 Harley® Bagger saddlebags.

Saddlebag lids are finished in Harley spec color "Vivid-Black" and can be special ordered in most standard 14-19 Harley factory colors for an extra.

This mount-from-the-top speaker/lid design is identical to factory Harley and makes for a water tight seal under the speaker itself, so that moisture is never allowed to enter the saddlebag.

J&M's **NEW** ROKKER XXR series 5X7" speakers are spec'd at 2 ohms impedance and an impressive 300 watts maximum power (175w RMS - 91db sensitivity), and are weatherproof from the top with their one piece carbon fiber cone and bridge mounted high-output dome tweeter.

These are THE most powerful 5X7" speakers you can buy for your Harley and the on-highway performance will exceed that of most 6X9 speakers available in the marketplace today.

Installation Instructions

1. If you are going to initially install these saddlebag lids without painting them, clean the underside of the lid seat area with alcohol, and apply the molded rubber seal all the way around the underside lip of each saddlebag lid. (then skip to step #3)
2. If you going to have them painted prior to installation, remove first the speakers and grills from each lid and have them painted to the color of your choice. Then install the molded rubber seal prior to continuing on to step #3.
3. Remove both left and right saddlebag lids, tether fasteners and latch/hinge assemblies from the stock saddlebag lids.
4. Remove both saddlebags, side covers, seat and fuel tank.
5. Carefully drill a 21mm or 13/16 diameter hole on the backside of the left saddlebag in the location shown. **Diagram A**
6. Install the provided rubber grommet into the hole, with pointed end facing towards wheel/tire. Then from the inside of the saddlebag, route the left side speaker harness (blue-orange/ blue grey). As per **Diagram B**
7. Connect the wire terminal plug to the connector socket of the J&M 5X7" ROKKER XXR speaker and route the speaker harness underneath the saddlebag lid tether strap and along the inside of the saddlebag as shown. **Diagram B**
8. Connect the forward section of the saddlebag lid speaker harness to the in-line wire plug and route the harness under the side cover along the frame, under the fuel tank, and into the fairing. Secure the harness using the provided tie-straps. **Diagram C**
9. Reinstall left saddlebag lid, tether fasteners and latch/hinge assembly, **SUBSTITUTING** the shorter bolt included in the hardware kit with the longer one from the stock lid assembly.
10. Repeat the entire process for the right-side saddlebag.
11. Reinstall the fuel tank, seat, and side covers.
12. Then reattach both left and right side saddlebags.

