



Installation

- 1. Remove stock system and retain all hardware.
- 2. Install front drag pipe first using stock flange bolts. Do not fully tighten bolts at this time.
- 3. Install rear drag pipe using stock flange bolts. Do not fully tighten bolts at this time.
- 4. Attach front and rear drag pipes to each other using supplied 3/8"-16 x 3/4" LG bolt.
- 5. Install front heat shield using supplied hose clamps. Tighten using a flathead screwdriver.
- 6. Install rear heat shield using supplied hose clamps. Tighten using a flathead screwdriver.
- 7. Align your Jardine drag pipe system as desired and securely tighten down all bolts.

A HISTORY OF QUALITY AND PERFORMANCE SINCE 1959

Learn more about motorcycle parts on our website.