


SLIP-ON EXHAUST, SS/POLISHED

HONDA VFR1200F 2010



| PARTS | INCLUDED |
|-------|----------|
|       |          |

| Ref. | Part Number  | Description                     | Qty |        |
|------|--------------|---------------------------------|-----|--------|
| 1)   | 00-200-02408 | Slip-on Midpipe Assembly        | 1   | A      |
| 2)   | 00-200-01349 | Polished Muffler Assembly       | 1   | ><br>ш |
| 3)   | 03-46-34864  | "C" Muffler Strap               | 1   | ¥      |
| 4)   | 07-27-38280  | Silicone Band for Muffler Strap | 1   |        |
| 5)   | 07-41-40004  | Short Swivel Spring, S/S        | 2   | 5 4    |
|      |              |                                 |     | N      |

### 18-1025-123-02

## SLIP-ON EXHAUST, SS/POLISHED

#### HONDA VFR1200F 2010

# TOOLS REQUIRED

- Ref.Description1)3/8" Drive Ratchet4)2)3" Extension5)5)5mm Allen Wrench
- 3) 12mm Socket

6) High-Temp Silicone sealer

## INSTALLATION INSTRUCTIONS

- 1) Make sure the motorcyle is cool and place securely on a service lift or center stand.
- 2) Remove the allen bolts securing the stock muffler shield to the muffler.
- 3) Disconnect the muffler butterfly valve cable from the muffler.
- 4) Loosen the clamp on the headpipe to midpipe connection.
- 5) Remove and retain the stock muffler mounting bolt, and nut.
- 6) Carefully remove the stock muffler assembly from the motorcycle.
- 7) Trace the butterfly vavle cable up to the motorcycle and disconnect it from the servo. NOTE: The cable will not need to be reused, the servo will operate as though it is still attached with no issues.
- **8)** Remove the clamp from the stock midpipe inlet. Loosely place the clamp on the new Jardine midpipe.
- 9) Slide the new midpipe onto the stock headpipe outlet tube. **NOTE:** Make sure the stock gasket is removed, as it will not be used with the new system.
- **10)**Slide the Jardine muffler onto the midpipe outlet. Secure the muffler to the midpipe using the two supplied swivel springs.
- **11)**Place the supplied silicone strap on the inside on the muffler strap. Position the muffler strap over the muffler so that it is in line with the passenger peg mount. Squeeze the strap tabs together, and with them both on the outside of the passenger peg mount secure using the stock hardware.
- **12)**Position the muffler in the best possible orientation. Fully tighten the midpipe clamp and the muffler strap mounting hardware.
- **13)**Clean all fingerprints and grease from the system. Start motorcycle and check for any leaks.