



18-2013-323-02

SLIP-ON RT1 EXHAUST, CARBON FIBER

YAMAHA FZ1
2006-11



PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)	00-200-02614	Slip-on Midpipe	1
2)	00-200-02409	Carbon Fiber Muffler Assembly	1
3)	03-46-34840	Muffler Strap	1
4)	07-27-38280	Silicone Muffler Strap Isolator	1
5)	07-3842068-35	T-Bolt Clamp, #68	1
6)	07-41-40004	Swivel Spring, Short	2
7)	01-7410125-27	M10-1.25 Hex Flange Nut	1

08-50-47640 REV. A

18-2013-323-02

SLIP-ON RT1 EXHAUST, CARBON FIBER

YAMAHA FZ1
2006-11

TOOLS REQUIRED

Ref.	Description
1)	3/8" Drive Ratchet
2)	3" Extension
3)	8mm Socket

Ref.	Description
4)	10mm Socket
5)	12mm Socket
6)	13mm Deep Socket

INSTALLATION INSTRUCTIONS

- 1) Make sure the motorcycle is cool and place securely on a service lift or stand.
- 2) Remove the two bolts securing the exhaust valve cover to the stock midpipe. (Fig. 1)
- 3) Loosen, and disconnect, the exhaust valve cables from the valve body.
- 4) Loosen the clamp securing the midpipe inlet to the headpipe outlet.
- 5) Remove the bolt, and nut, securing the stock muffler to the passenger peg mount. (Fig. 1)
- 6) Remove the stock muffler assembly from the motorcycle.
- 7) Remove the rider seat.
- 8) Trace the exhaust valve cables to the servo motor located under the rider seat.
- 9) Disconnect and remove the exhaust valve cables from the motorcycle.
NOTE: Do not disconnect any wiring controlling the exhaust valve motor. This will cause an engine fault code.
- 10) Reinstall the rider seat.
- 11) Place the supplied T-Bolt Clamp onto the notched inlet of the new Midpipe.



PERFORMANCE DELIVERED!

18-2013-323-02

SLIP-ON RT1 EXHAUST, CARBON FIBER

YAMAHA FZ1
2006-11

INSTALLATION INSTRUCTIONS

- 12) Slide the new Midpipe over the stock headpipe outlet, until fully seated. Do not tighten t-bolt clamp at this time.
- 13) Slide the new RT-1 Muffler onto the midpipe until fully seated.
- 14) Apply the supplied Silicone Muffler Strap Isolator to the inside of the supplied Muffler Strap. Work the muffler strap over the muffler until it is positioned in line with the passenger peg mounting bracket.
NOTE: The offset in the muffler strap should be facing inward toward the motorcycle.
- 15) Using the original bolt and supplied M10-1.25 Hex Flange Nut, loosely secure the muffler strap to the passenger peg mount.
- 16) Secure the muffler to the midpipe using the two supplied Swivel Springs.
- 17) Position the exhaust system in the best possible orientation, then fully tighten the t-bolt clamp and muffler mounting hardware.
NOTE: When tightening the t-bolt clamp, make sure it covers the notches on the midpipe inlet.
- 18) Clean all fingerprints and grease from the exhaust system.
- 19) Start your motorcycle and go ride!



PERFORMANCE DELIVERED!

Learn more about motorcycle parts on our website.