




19-2012-123-02

SLIP-ON RT5 EXHAUST, POLISHED

YAMAHA FZ8  
2011



**PARTS INCLUDED**

Ref.	Part Number	Description	Qty
1)	00-200-02615	Slip-on Midpipe	1
2)	00-200-02616	Polished Muffler Assembly	1
3)	07-3842063-35	T-Bolt Clamp, #63	1
4)	07-41-40004	Swivel Spring, Short	1
5)	01-530812520-27	M8-1.25x20mm Hex Flange Head Bolt	1

08-50-47643 REV. A

19-2012-123-02

## SLIP-ON RT5 EXHAUST, POLISHED

YAMAHA FZ8  
2011

### TOOLS REQUIRED

Ref.	Description
1)	3/8" Drive Ratchet
2)	3" Extension
3)	8mm Socket



Ref.	Description
4)	10mm Socket
5)	12mm Socket
6)	13mm Deep Socket



### INSTALLATION INSTRUCTIONS

- 1) Make sure the motorcycle is cool and place securely on a service lift or stand.
- 2) Remove the two bolts securing the midpipe heat shield to the stock muffler. (Fig. 1)
- 3) Loosen the clamp securing the muffler inlet to the headpipe outlet.
- 4) Remove the bolt, and nut, securing the stock muffler to the passenger peg mount. (Fig. 1)
- 5) Remove the stock muffler assembly from the motorcycle.
- 6) Place the supplied T-Bolt Clamp onto the notched inlet of the new Midpipe.
- 7) Slide the new Midpipe over the stock headpipe outlet, until fully seated.
- 8) Slide the new RT-5 Muffler onto the midpipe until fully seated. Using the supplied M8-1.25x20mm Hex Flange Head Bolt, and original nut, loosely secure the muffler to the passenger peg mount. (Fig. 2)
- 9) Secure the muffler to the midpipe using the supplied Swivel Spring.
- 10) Position the exhaust system in the best possible orientation, then fully tighten the t-bolt clamp and muffler mounting hardware.  
*NOTE: When tightening the t-bolt clamp, make sure it covers the notches on the midpipe inlet.*



PERFORMANCE DELIVERED!

19-2012-123-02

SLIP-ON RT5 EXHAUST, POLISHED

YAMAHA FZ8  
2011

## INSTALLATION INSTRUCTIONS

11) Clean all fingerprints and grease from the exhaust system.

12) Start your motorcycle and go ride!



PERFORMANCE DELIVERED!

Learn more about motorcycle parts on our website.