



19-7708-323-02

SLIP-ON RT5 EXHAUST, CARBON FIBER

TRIUMPH SPEED TRIPLE  
2005-10



**PARTS INCLUDED**

Ref.	Part Number	Description	Qty
1)	00-200-02500	Slip-on Collector	1
2)	00-200-02501	Midpipe Assembly, Left	1
3)	00-200-02502	Midpipe Assembly, Right	1
4)	00-200-02508	Carbon Fiber Muffler Assembly, Left	1
5)	00-200-02510	Carbon Fiber Assembly, Right	1
6)	07-41-35929	Swivel Spring, Long	2
7)	07-41-40004	Swivel Spring, Short	2
8)	01-530812550-27	M8-1.25x50mm Hex Flange Head Bolt	2

08-50-47414 REV. A

**PERFORMANCE DELIVERED!**

19-7708-323-02

SLIP-ON RT5 EXHAUST, CARBON FIBER

TRIUMPH SPEED TRIPLE  
2005-10

## TOOLS REQUIRED

Ref.	Description
1)	3/8" Drive Ratchet
2)	3" Extension
3)	8mm Socket



Ref.	Description
4)	10mm Socket
5)	12mm Socket
6)	13mm Deep Socket



## INSTALLATION INSTRUCTIONS

- 1) Make sure the motorcycle is cool and place securely on a service lift or stand.
- 2) Remove the seat.
- 3) Remove the screws securing the right & left tail section side pods to the sub-frame. Carefully remove the side pods. (Fig. 1 & 2)
- 4) Remove the two bolts securing the heat shield covering the stock right side muffler. Remove the heat shield. (Fig. 3)
- 5) Loosen the stock right side muffler inlet clamp. (Fig. 4)
- 6) Remove the bolt and nut securing the stock right side muffler to the motorcycle sub-frame. (Fig. 3 & 5) Remove the right side muffler.
- 7) Repeat Steps #4-7 to remove the left side muffler.
- 8) Loosen the clamp securing the header assembly to the stock midpipe inlet. (Fig. 6)
- 9) Remove the two bolts securing the right side rider peg to the motorcycle frame. Carefully allow the rider peg assembly to hang in place.  
*NOTE: This allows easier access to the midpipes.*



PERFORMANCE DELIVERED!

19-7708-323-02

SLIP-ON RT5 EXHAUST, CARBON FIBER

TRIUMPH SPEED TRIPLE  
2005-10

## INSTALLATION INSTRUCTIONS

- 10) Slide the midpipe assembly out of the headpipe outlet and carefully remove the complete assembly from the motorcycle.

*NOTE: Make sure the stock gasket stays in place, in the headpipe outlet.*

- 11) Slide the new Slip-on Collector into the headpipe outlet. (Fig. 7) Do not tighten the headpipe clamp at this time.
- 12) Slide the new Right Side Midpipe into the upper collector outlet tube. Using one supplied Long Swivel Spring, secure to the collector.
- 13) Slide the new Left Side Midpipe into the lower collector outlet tube. Using the remaining supplied Long Swivel Spring, secure to the collector.
- 14) Slide the new Right Side Muffler onto the outlet of the right side midpipe. Using one supplied M8-1.25x50mm Hex Flange Head Bolt, and one original muffler mounting nut, loosely secure the muffler to the sub-frame mounting point.
- 15) Using one supplied Short Swivel Spring, secure the right side muffler to the right side midpipe.
- 16) Slide the new Left Side Muffler onto the outlet of the left side midpipe. Using the remaining supplied M8-1.25x50mm Hex Flange Head Bolt, and one original muffler mounting nut, loosely secure the muffler to the sub-frame mounting point.
- 17) Using the remaining supplied Short Swivel Spring, secure the left side muffler to the left side midpipe.



Fig. 3



Fig. 4



Fig. 5

PERFORMANCE DELIVERED!

19-7708-323-02

SLIP-ON RT5 EXHAUST, CARBON FIBER

TRIUMPH SPEED TRIPLE  
2005-10

## INSTALLATION INSTRUCTIONS

- 18) Position the exhaust system so that it is in the best possible orientation. Fully tighten the muffler mounting hardware, and the headpipe outlet clamp.
- 19) Clean all fingerprints and grease from the exhaust system.
- 20) Reinstall the right side rider footpeg assembly. Tighten bolts to factory specification.
- 21) Reinstall the tail section side pods.
- 22) Reinstall the rider seat.
- 23) Start your motorcycle and go ride!



PERFORMANCE DELIVERED!

Learn more about motorcycle parts on our website.