



### PRE-INSTALLATION INFORMATION

<b>Estimated Time</b>	30 minutes
<b>Tools Needed</b>	Screwdriver (Varies by vehicle)
<b>In the Box</b>	(x1) Model 8900 Evolution Headlight
<b>Wire Functions</b>	Black = Ground White = High Beam Yellow = Low Beam Red = Front Position ( <i>ECE Versions Only</i> )
<b>Input Voltage</b>	12-24V DC
<b>Operating Voltage</b>	9-32V DC

### Regulatory Compliance



### Pre-Installation Guidelines

1. Read all safety notes and mounting guidelines before installing the product. Verify that all parts listed under "In the Box" are present and complete.
2. Inspect the product for damage. **DO NOT** install the product if there is any damage. Contact the authorized retailer where you purchased it to initiate a warranty claim if there is damage.
3. Verify that all power supply and/or charging systems comply to the specified voltage limits for the light.

#### PRODUCT WARRANTY:

If you have issues with a J.W. Speaker product, please contact the authorized retailer where you purchased it.

To properly install this light you should have a good understanding of automotive electrical procedures and systems, and proficiency in the installation of headlights. **IF YOU DO NOT, PLEASE SEEK PROFESSIONAL ASSISTANCE.**

### Installation Instructions

1. Turn off the vehicle and disconnect the battery.
2. Remove the existing headlights from the bumper. Be careful not to damage the bumper and keep all hardware that attaches the headlight to the vehicle.
3. Unplug the connector of the existing headlight.
4. Plug in the Model 8900 Evolution connector.
5. Lay and secure wires to avoid any pulling or abrasion that may damage the wires or light.
6. Install the headlight with the existing hardware into the bumper, with the J.W. Speaker logo oriented at the bottom.
7. Aim the lights (continued on next page).