

## INSTALLATION INSTRUCTIONS

### KURYAKYN BY KELLERMANN FRONT MOUNTS FOR ROAD GLIDE

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE**

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

1	Left Mount	2	1/4 - 20 x 1.125" Button Head Cap Screws
1	Right Mount	2	M8x1.25" Nut

#### YOU WILL ALSO NEED:

Standard and metric hex bit set and socket set, in-lbs (Nm) torque wrench

**NOTICE**

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

**NOTICE**

THESE MOUNTS CAN BE USED WITH ANY KURYAKYN BY KELLERMANN LIGHTS. IF USING WITH ATTO, MICRO S OR RHOMBUS S, P/N 2568 ADEPTER STUDS (SOLD SEPARATELY, QTY 2 NEEDED) IS REQUIRED FOR PROPER INSTALLATION.

**STEP 2** Remove main fuse.

**STEP 3** Refer to PIC 2. Unfasten and remove windshield. Unfasten the outer fairing, disconnect the turn signal wires located near the top of the outer fairing, and remove the outer fairing. Set hardware aside, most of it will be reused.

*Note: Refer to motorcycle's service manual for additional assistance.*

**STEP 4** Refer to PIC 3 and 4. Unfasten the turn signal wires from the clips on the inside of the outer fairing.

**STEP 5** Unfasten and remove the existing front turn signals from the outer fairing. Set the rubber gasket aside, it will be reused. Pay attention to which gasket belongs to each side.



## INSTALLATION INSTRUCTIONS

### KURYAKYN BY KELLERMANN FRONT MOUNTS FOR ROAD GLIDE

-CONTINUED-

**STEP 6** Refer to PIC 5.  
**IF ADAPTER IS NEEDED:**  
Locate the sold separately Kellermann light and adapter. Apply a small amount of blue loctite to the treads of the light and to the adapter. Feed the wire of the light through the adapter and secure it onto the light.

**IF ADAPTER IS NOT NEEDED:**  
Locate the sold separately Kellermann light. Apply a small amount of blue loctite to the treads of the light.

**STEP 7** Locate the provided Left (clutch-side) and Right (brake-side) Mount. Align and test fit the mounts on their corresponding side of the outer fairing. The debossed hole is the hardware mounting hole and should be towards the rear.

**STEP 8** Refer to PIC 5. Feed the wire of the light through the flat surfaced hole on the mount. On the back side of the mount secure the light to the mount using the provided nut. Fully tighten hardware.

*Note: Be aware of the direction of the light on the Left and Right Mount. Be sure the turn signal is facing the correct direction before mounting it on the outer fairing.*

**STEP 9** Refer to PIC 5. Place OEM gasket on the backside of the provided mounts. Be aware of the left and right side gaskets and mounts.

**STEP 10** Be sure to align the left mount and light assembly on the left (clutch) side and right mount and light assembly on the right (brake) side. Insert the wires through the hole of the outer fairing from where the existing turn signal wire was.

**STEP 11** Refer to PIC 6. Align and place the mount and light assembly on the outer fairing. Use masking tape to hold the wires in place along in inside of the outer fairing. Be sure the wires come out near the top of the outer fairing so it can be plugged into the wiring harness later.

*Note: If light assembly and mount are not tightly held in place on the outside of the fairing, secure in place with masking tape for the time being.*

**STEP 12** Refer to the installation instructions that were provided with the light to complete the installation of the light to the motorcycle. Reinstall main fuse and test for proper functionality before moving forward.

**PIC 5**



**PIC 6**



**PIC 7**



## INSTALLATION INSTRUCTIONS

### KURYAKYN BY KELLERMANN FRONT MOUNTS FOR ROAD GLIDE

-CONTINUED-

**STEP 13** Refer to PIC 8. Locate provided two (2) button head cap screws. Insert each screw into the mounting hole of the new mounts. Reinstall the outer fairing and windshield. Fully tighten all hardware.

**TORQUE VALUE FOR TURN SIGNAL MOUNTING SCREWS:**  
48-60 in-lbs (5.4-6.8 Nm)

**TORQUE VALUE FOR OUTER FAIRING UPPER SCREWS (NEAR SPEAKERS):**  
20-30 in-lbs (2.3-3.4 Nm)

**TORQUE VALUE FOR OUTER FAIRING LOWER SCREWS (ALSO AIR DEFLECTOR):**  
8-15 in-lbs (0.9-1.4 Nm)

**TORQUE VALUE FOR WINDSHIELD SCREWS:**  
8-12 in-lbs (0.9-1.4 Nm)

#### NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

