



Installation Instructions

Part Number KA-6512

Congratulations, you have purchased the finest [air filter](#) that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modifications will be required. However the following procedure **MUST** be followed to ensure a proper fit and seal of the K&N® Air Filter.

INSTALLATION

1. Remove the stock air filter.
2. Clean the inside of the air box and any sealing surfaces.
3. Using the supplied spacer (Fig. 1), insert spacer into air filter (Fig. 2). Using a screwdriver, push spacer all the way down into the filter (Fig. 3). You will feel a click once the button has reached the correct position.
4. With spacer installed, turn filter over to ensure spacer has been installed correctly (Fig 4.).
5. Install K&N® filter into air box. Insert screw and tighten filter into the air box (Fig 5.).
6. Re-install air box lid and tighten.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.

* Pictures in this instruction sheet are for reference only. Your vehicle may look different. *

Fig.1



Fig.2



Fig.3



Fig.4



Fig.5

