



## MAGNUM™ QUICK CLAMPS 1-1/2" I.D. 1001

## **PARTS INCLUDED**

- 2 Magnum Quick Clamps
- 2 1/2" I.D. x 3/32" Thick Spacer
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

## THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

## **MAGNUM QUICK CLAMP ASSEMBLY** \* CLEVIS OR OFFSET ARM \* INTERNAL INTERNAL LOCK LOCK WASHER WASHER **SPACER** WASHER NOTE: WASHER MUST BE INSTALLED **BETWEEN CLAMP HALVES! FAILURE TO DO SO MAY RESULT** \*CLEVIS, BOLT, AND LOCKING WASHERS IN UNSECURE CLAMPING OR **DAMAGE TO THE CLAMP!** NOT INCLUDED IN ALL KITS

Ride On!