



REAR SHIFT LEVER ELIMINATOR 1046

FITS '86-UP FLST MODELS

PARTS INCLUDED

- 1 Rear Shift Eliminator Spacer, Chrome
- 1 Plastic Insert
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

Allen wrenches.

ATTENTION! A factory service manual may be helpful in performing this installation. Do not attempt to perform this installation if you are not confident in your ability to complete all steps in the procedure; consult a trained technician.

PROCEDURE

STEP 1 Remove the heel and toe shift levers.

STEP 2 Press the plastic insert and chrome spacer in place over the splined shift shaft.

STEP 3 Reinstall the toe shift lever.

STEP 4 Slide the shaft outward until you have enough room to reinstall the toe shift lever. Tighten the pinch bolts on the shift arm and front shift lever securely.

ATTENTION! Use blue Loctite on the both pinch bolt; be sure the bolt is tightened securely before riding.

Ride On!