



TRANSMISSION SHIFT ARM COVER

1068

**FITS: ALL '01-UP ELECTRA GLIDES, ROAD GLIDES, STREET GLIDES AND ROAD KINGS;
ALL '09-UP TRI GLIDES AND STREET GLIDE TRIKES; ALL '01-UP SOFTTAILS AND DYNAS**

PARTS INCLUDED

- 1 Transmission Shift Arm Cover Assembly
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Combination Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 As shown in PIC 1, remove the rear of the shift linkage from the transmission shift arm using a 7/16" wrench.

STEP 3 Test fit the Shift Arm Cover to the shift arm of the transmission.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 4 Clean the shift arm with the included alcohol pad, wipe dry with a clean cloth. Be sure that the mounting area is clear of all contaminants to ensure proper adhesion.

-cont.-

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 5 Rub the adhesive backing on the Shift Arm Cover to activate the adhesive. Remove the tape backing and apply the Shift Arm Cover to the shift arm.

STEP 6 Hold the Cover in place for one minute, full bonding strength will occur in 24 hours.

STEP 7 Re-assemble the shift linkage to the shift arm.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

CAUTION! Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

Ride On!

Kuryakyn[®]

PIC. 1



PIC. 2



PAGE

2

TRANSMISSION SHIFT ARM COVER INSTALLATION

Shop for other motorcycle foot controls and pegs on our website.