



# ZOMBIE WINDSHIELD TRIM

1198

FITS: '96-UP FLHT, FLHTC, FLHTCU, FLHX

## PARTS INCLUDED

- 1 Zombie Windshield Trim
- 1 Hardware Kit Including:
  - 2 1/4" Flat Washer
  - 1 1/4"-20 x 5/8 Socket Button Head Cap Screw (SBHCS)
  - 2 1/4"-20 x .625" Knurled Spike Fasteners
  - 2 1/4"-20 x 1" Knurled Spike Fasteners
  - 1 Zombie Emblem
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

## THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

## TOOLS SUGGESTED

Set of hex wrenches, Torx wrenches, combination wrenches

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**NOTE; IF INSTALLING WINDSHIELD TRIM ON KÜRYAKYN® AIRMASTER™ FAIRING, USE THE 1/4"-20 X 1" KNURLED SPIKE FASTENERS.**

## PROCEDURE

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition.



**STEP 2** Remove the three Torx head screws that secure the windshield shown in [PIC.1](#). Set these aside, they will not be used again.

**STEP 3** Place the trim in place, lining up the holes in the trim with the holes in the in the windshield.

**STEP 4** Place the 1/4" - 20 x 5/8" SBHCS screw in the center hole without a washer, do not tighten.

**STEP 5** Place the appropriate Knurled Spike Fasteners in the outside holes with the 1/4" flat washers as shown in [PIC.2](#), do not tighten.

**STEP 6** Tighten the screws, being careful not to over tighten them, which may damage the trim.

**STEP 7** Place the zombie emblem in place with head facing up as shown in [PIC.3](#).

*Ride On!*

**PIC.2**



**PIC.3**

