

STEP 3 Place the included rubber gasket onto the back of the Chrome Trim. The tall raised lip on the gasket goes on the top of the Chrome Trim and faces the windshield. PIC 2

STEP 4 Holding the rubber gasket and Chrome Trim together, place it on the outer fairing lining up the holes in the trim with the holes in the in the outer fairing and windshield. Loosely install a 1/4" - 20 x 5/8" button head cap screw in the center hole. PIC 3

NOTE: If installing windshield trim on Küryakyn Airmaster fairing, use a 1/4"-20 x 7/8" button socket cap screw in the center hole .

STEP 5 Loosely install a 1/4" - 20 x 5/8" button head cap screw in each outside hole. PIC 4

NOTE: If installing windshield trim on Küryakyn Airmaster fairing, use the 1/4"-20 x 7/8" button socket cap screws in the outside holes.

STEP 6 Making sure the short lip of the rubber gasket is just above the top of the Chrome Trim, PIC 4, tighten the center fastener first **(when tightening the fasteners, make sure the head of the fastener is centered in the recess of the Trim. You may need to push down on the Trim slightly to center the fasteners.)**, then the outside fasteners, being careful not to over tighten them, which may damage the trim, windshield or fairing.



NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.