



SADDLE SHIELD HEAT DEFLECTORS **1317**

FITS: ALL '99-UP DYNA MODELS

PARTS INCLUDED

- 1 Saddle Shield Assembly
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Hex Wrenches, Screwdrivers

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

STEP 2 Remove the seat from the motorcycle.

STEP 3 As shown in PIC 1, test fit the Saddle Shield to the seat. Make sure that the Saddle Shield fits in the seat cut-out.

STEP 4 As shown in PIC 2, test fit the Saddle Shield to the frame. Make sure that it sits flat against the frame and that it does not touch the fuel tank or side panels. Mark the area of best fit using masking tape, this will help for final installation.

NOTE If the Saddle Shield does not fit on the frame, you may need to remove some plastic clips securing a wiring harness in place

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 5 Clean the mounting area of the frame with the supplied alcohol pad. Dry the area with a clean cloth.

NOTE If the frame is excessively dirty, clean the area with warm water and a mild soap. Rinse thoroughly and dry completely with a clean cloth. Proceed to clean with the alcohol pad and dry completely

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 6 Rub the adhesive backing to activate the adhesive. Remove the tape backing and install on the bike using any markings made in Step 4 as a guide. Press and hold the Saddle Shield in place for one minute. Full bonding strength will occur in 24 hours.

STEP 7 As shown in PIC 3, replace and secure the seat. Inspect the Saddle Shield - make sure that there is no contact between the Saddle Shield and other components.

Ride On!

Kuryakyn[®]

PIC. 1



PIC. 2



PIC. 3



PAGE

2

SADDLE SHIELDS INSTALLATION