

INSTALLATION INSTRUCTIONS

MIRROR STEM EXTENDERS

1444

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Mirror Stem Extender Assemblies
- 2 Long Jam Nuts

YOU WILL ALSO NEED:

Set of Hex Wrenches, Combination Wrenches, Blue Thread-Lock

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Remove the stock mirror by removing the acorn nut (PIC 1) and washer(s). Save the washer(s) and acorn nut, they will be reused. Note the order they were disassembled.

STEP 3 As shown in PIC 2, install the mirror stem extenders in place where the stock mirrors were removed. Secure loosely with the washer(s) and acorn nut.

Note: Add a small amount of blue thread-lock to the threaded stud before installing the acorn nut.

STEP 4 As shown in PIC 3, thread the long jam nuts on to the stock mirror stem. The cupped end of the long jam nut should go on first with the hex end being closest to the end of the stem.



PIC 1



PIC 2

INSTALLATION INSTRUCTIONS

MIRROR STEM EXTENDERS

1444

-CONTINUED-

STEP 5 As shown in PIC 4, thread the stock mirror with long jam nut installed in to the mirror stem extender installed in Step 3.

Note: Add a small amount of blue thread-lock to the threaded mirror stem before installing on the mirror stem extender.

STEP 6 As shown in PIC 4, position the mirror as desired and tighten the long jam nut against the mirror stem extender.

STEP 7 Tighten the acorn nut to secure the entire assembly to the controls.

STEP 8 Repeat all steps for the opposite side.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

PIC 3



PIC 4

