



GLOVE BOX CUBBY for GL 1800

1669

PARTS INCLUDED

- 1 Chrome Glove Box Door Assembly
- 1 Foam Glove Box Insert
- 1 Left Cubby Cover
- 1 Right Cubby Cover
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING	THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTICE	IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.
---------------	---

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.
- STEP 2** Remove the glove box door from the motorcycle. PIC 1 Set this aside, you may want to reuse it.

- STEP 3** Place the Foam Glove Box insert into the opening. PIC 2

NOTE: The small holes and grooves in the Foam Glove Box insert are intended to allow any liquid/rain to drain in the OEM manner.



STEP 4

Decide if you would like to use one, both or neither of the Cubby Covers for the Glove Box Cubby. PIC 3 The Cubby Covers snap into place. The covers are designed to be semi-permanent, but may be removed once installed. **Care will have to be taken not to damage the covers or the chrome trim when removing them.** To remove the Cubby Covers, open the Glove Box and hold the outside of the Cubby Cover with one hand, then gently press the Cubby Cover outward from the inside with your other hand.

WARNING DO NOT ATTEMPT TO REMOVE THE CUBBY COVERS WHILE OPERATING THE MOTORCYCLE!

NOTICE The Glove Box Cubby with both Cubby Covers installed is designed to be weather resistant. It is not waterproof.

STEP 5

Place the Chrome Glove Box Door assembly into the OEM location and lock into place. PIC 4 The Chrome Glove Box Door will operate the same as the OEM door.

NOTE: The OEM door maybe be used in place of the Chrome Door assembly (it will fit over the foam insert) if needed for added security.

WARNING ENSURE THAT THERE IS CLEARANCE BETWEEN ANY OBJECT IN THE GLOVE BOX CUBBY AND THE HANDLEBARS WHEN THE HANDLEBARS ARE TURNED. INSUFFICIENT CLEARANCE MAY CAUSE DAMAGE TO THE MOTORCYCLE OR CAN CAUSE LOSS OF CONTROL THAT MAY RESULT IN SEVERE INJURY OR DEATH.

WARNING TO PREVENT POSSIBLE LOSS OF CONTROL, WHICH MAY RESULT IN SERIOUS INJURY OR DEATH, WE DO NOT RECOMMEND REMOVING OR REPLACING ANY OBJECT IN THE GLOVE BOX CUBBY WHILE RIDING THE MOTORCYCLE.

NOTICE Küryakyn recommends using sealable containers with the Glove Box Cubby.

NOTICE It is the installer's responsibility to ensure that there is adequate clearance between any container in the Glove Box Cubby and any painted surfaces. Küryakyn is not responsible for any damage due to inadequate clearance.

NOTICE Ensure that the Glove Box Cubby is secure in the glove box. Küryakyn is not responsible for any damage, or stolen items, from the use of the Glove Box Cubby or from the Glove Box Cubby not being properly secured to the motorcycle.

