



5 INCH DARK SMOKE WINDSHIELD, '96-'13

1773

Thank You For Choosing Kuryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions and notices regarding the installation, use, and care of this product.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Windshield
- 1 Installation Instructions

YOU WILL ALSO NEED:

Phillipshead screwdriver

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn IGN OFF.

NOTICE

Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

STEP 2 Remove the three (3) existing windshield screws; set them aside, they will be reused.

STEP 3 Remove the existing windshield; set it aside.

STEP 4 Ensure that the inner surfaces of the fairing are clean and free of debris.

STEP 5 Remove and discard the protective film from the new Windshield.

STEP 6 Slide the new Windshield into place, align the holes and secure with the existing screws.

NOTICE

It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.