



### LOWER TRIPLE TREE WIND DEFLECTOR, TOURING, SATIN BLACK

1805

Thank You For Choosing Kuryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

#### **WARNING**

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

#### **NOTICE**

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Lower Wind Deflector
- 1 Installation Instructions

YOU WILL ALSO NEED:

Set of hex bit sockets and ratchet, ft lbs/Nm torque wrench

#### **NOTICE**

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**. Allow the engine and exhaust system to cool.

#### **NOTICE**

Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

- STEP 2** Refer to **PIC 1**. Locate and remove the top pinch screws from the clutch-side (left) and brake-side (right) lower fork bracket.

There are two pinch screws on each side of the lower fork bracket.

**DO NOT REMOVE THE BOTTOM PINCH SCREWS!**

- STEP 3** Refer to **PIC 2**. Align the Wind Deflector with the two holes; secure it with the two screws.

Torque the two screws to 14-18 ft lbs (19.0-24.4 Nm).

