

## INSTALLATION INSTRUCTIONS

### MIRROR ADAPTERS, BLACK

1891

### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Mirror Adapters

### YOU WILL ALSO NEED:

Set of Hex Wrenches, Metric and Standard combination wrenches

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.
- STEP 2** Refer to PIC 1. Locate Mirror Adapter and Flange Nut assembly. Place a drop of Red Loctite on the end of the adapter that threads into the mirror and thread the adapter into the stem of the mirror that you are mounting to the bike until it bottoms. DO NOT exceed 20 foot pounds of torque when tightening the adapter to the mirror stem. Secure with set screw if applicable to your mirrors.



- STEP 3** Refer to PIC 2. Thread the flange nut until loosely seated against stop.



## INSTALLATION INSTRUCTIONS

### MIRROR ADAPTERS, BLACK

1891

-CONTINUED-

- STEP 4** Thread mirror and adapter assembly to the stock mirror mounting point on right side of bike until loosely seated. Back (un-thread) the assembly out to the desired vision position.
- STEP 5** Refer to PIC 3. Thread the flange nut down the adapter to the stock mirror mounting point. Finger tighten.
- STEP 6** Holding the adapter with a wrench in adjusted position, tighten flange nut to the stock mirror mounting point.
- STEP 7** Tighten all fasteners.
- STEP 8** Repeat for the other side.

#### NOTICE

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

