

INSTALLATION INSTRUCTIONS

RAISED MIRROR ADAPTERS, BLACK

1892

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|------------------------|---|-----------------------------------|
| 2 | Raised Mirror Adapters | 1 | Hardware Kit containing: |
| | | 2 | 5/16" Internal Tooth Lock Washers |

YOU WILL ALSO NEED:

Set of Metric combination wrenches, screwdrivers, Torx drivers, hex wrenches

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn IGN OFF.

STEP 2 Remove the existing mirrors.

Refer to PIC 1. It may be necessary to loosen or remove the lever mount and rotate it rear ward to gain enough clearance to un-thread the existing mirrors.

Use a piece of masking tape and a marker to mark the location of the lever mount.

NOTICE AVOID DAMAGE TO THE MOTORCYCLE. PROTECT PAINTED SURFACES WITH A SOFT CLOTH OR BLANKET.

STEP 3 Refer to PIC 2 and 3. Thread one of the included Raised Mirror Adapters into the mirror mount hole.

Ensure that the jam nut has been threaded all the way to the top of the threads; this will allow for the most thread engagement in the lever mount.

Leave the Adapter and jam nut loose for now to allow for adjustment.



INSTALLATION INSTRUCTIONS

RAISED MIRROR ADAPTERS, BLACK

1892

-CONTINUED-

STEP 4 Place one of the included 5/16" Internal Tooth Lock Washers over the top of the adapter.

STEP 5 Refer to PIC 4. Thread the new mirror onto the Adapter; using a 12MM wrench to hold the adapter, tighten the mirror as shown in PIC 5.

STEP 6 Follow the specific instructions included with the new mirror to complete the installation.

STEP 7 If necessary, rotate the lever mount back into place and tighten the screws.

STEP 8 Adjust the mirror stem to your liking; use a 13MM wrench to tighten the jam nut down against the lever mount; use a 12MM wrench to hold the adapter in place while the jam nut is being tightened.

STEP 9 Repeat for the other side.

STEP 10 Adjust the mirrors to your liking and ensure that they do not interfere with the proper operation of the motorcycle **BEFORE** riding.

NOTICE

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

